

FIRESTOP CENTRE

Authorised New Zealand Distributor
Ph (09) 483 4000 www.firestopcentre.co.nz

AGNI-Wrap in a Shaftwall (min 41mm) PVC Conduit 25mm, empty or filled with cables FRR -/60/60

System ID# FC453

Step-by-step installation instructions:

- 1. Ensure the aperture is free from dust and debris.
- 2. Insert one revolution of AGNI-Wrap 50 (20mm inside & 30mm outside the wall) into the annular gap each side of the wall.
- 3. Apply 10mm deep AGNI-Black between AGNI-Wrap 50 and the conduit, finishing flush with the edge of the AGNI-Wrap 50.
- 4. Apply 30mm x 30mm AGNI-Black fillet/cone around the AGNI-Wrap.



Technical Information

Teetimear information	
Substrate	Min. 25mm Shaftliner & 16mm fire-rated plasterboard wall (Shaftwall system)
Service range	DN25mm uPVC rigid conduit, empty or filled with up to 3 x Data cables + 3 x Alarm cables + 3 x 4.8mm Optic cables
Annular gap	5.8-8.7mm
AGNI-Products	AGNI-Wrap 50, AGNI-Black
Protection installation	From both sides of the wall

Compliance Information

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/60/60
Reference	RIRF25006



8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Disclaime


Date 21.04.2025



FIRESTOP CENTRE

Authorised New Zealand Distributor
Ph (09) 483 4000 www.firestopcentre.co.nz

System ID# FC453



Technical Information

Substrate	Min. 25mm Shaftliner & 16mm fire-rated plasterboard wall (Shaftwall system)
Service range	DN25mm uPVC rigid conduit, empty or filled with up to 3 x Data cables + 3 x Alarm cables + 3 x 4.8mm Optic cables
Annular gap	5.8-8.7mm
AGNI-Products	AGNI-Wrap 50, AGNI-Black
Protection installation	From both sides of the wall

Compliance Information

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/60/60
Reference	RIRF25006



8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Disclaimer

Date 21.04.2025