

FIRESTOP CENTRE

Authorised New Zealand Distributor
Ph (09) 483 4000 www.firestopcentre.co.nz

AGNI-Seal in 1x13mm P'bd Wall or 90mm Concrete Wall Copper or Steel Pipe (32mm - 150mm diam) FRR -/60/-

Step-by-step installation instructions:

- 1. Ensure the aperture is free from dust and debris.
- 2. Apply AGNI-Seal into the annular gap around the service to the full depth of the lining.
- 3. Apply 30mm x 30mm AGNI-Seal fillet/cone around the service.

<u>NOTE</u>: Tested all sizes with copper pipes. Steel pipes approved by virtue of AS1530.4 clause 10.12.3.2

Fechnical Information • Min. 64mm timber or steel stud wall with a minimum of one layer of 13mm (or greater) FR plasterboard on each side, with or without insulation. • Min. 90mm concrete /masonry wall Service range Up to DN150mm copper/steel pipes DN32mm - 9.5 - 11.5mm DN100mm - 6 - 9mm DN150mm - 8 - 9.5mm

AGNI-Seal

From both sides of the wall

Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/60/-
Reference	PF24026

System ID# FC247

Agnitek

8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

Date

03.04.2025

Disclaimer


AGNI-Products

Protection installation




AGNI-Seal in 1x13mm P'bd Wall or 90mm Concrete Wall Copper or Steel Pipe (32mm - 150mm diam)

FRR -/60/-



Technical Information

Substrate	Min. 64mm timber or steel stud wall with a minimum of one layer of 13mm (or greater) FR plasterboard on each side,
	with or without insulation. • Min. 90mm concrete /masonry wall
Service range	Up to DN150mm copper/steel pipes
Annular gap	DN32mm - 9.5 - 11.5mm
	DN100mm - 6 - 9mm
	DN150mm - 8 - 9.5mm
AGNI-Products	AGNI-Seal
Protection installation	From both sides of the wall



Standards	AS1530.4-2014, AS4072.1-2005
FRR/FRL	-/60/-
Reference	PF24026



8 Clare St Bayswater VIC 3153, AUSTRALIA www.agnitek.com.au

03.04.2025 Date