




System FC731

Penetration Detail: PVC Floor Waste (FWG) fire-stopped with Allproof Low Profile Fire Collar

Separating Element: Min. 150mm thick Hollow Core Concrete Floor



ALLPROOF
INDUSTRIES

- Installation Instructions:**
1. Ensure substrate around pipe is flat and free from obstructions.
 2. Open the collar and position it around the pipe.
 3. Slide the tab through the slot and fold it back to lock.
 4. Secure the collar using M6 x 25mm masonry or M6 x 45mm DBZ wedge anchors. Do not use plastic or nylon-based fixings.
 5. Install only from underside of slab.

Services & Ratings (FRR)

Service Penetration	Pipe Size	Slab Depth	Collar Size	Core Hole Size	FRR
PVC floor waste	80mm	150mm	ALLFC80	87mm	-/60/60
PVC floor waste	100mm	150mm	ALLFC100	112mm	-/60/60
PVC floor waste	80mm	200mm	ALLFC80	87mm	-/90/90
PVC floor waste	100mm	200mm	ALLFC100	112mm	-/90/90

Compliance

Compliance BRANZ Appraisal No. 1088(2025)
Standards AS1530.4-2014 & AS4072.1-2005

Firestop Centre Technical support:
Tel: +64 9 483 4000
info@firestopcentre.co.nz
www.firestopcentre.co.nz

Drawing Rev: 1.1

Scale: NTS

Disclaimer: Firestop Centre may change product specifications without notice as part of our ongoing development and testing. All information in this document is provided in good faith and for guidance only. All drawings are for illustration purposes only and may not reflect the actual product. Since we cannot control how the product is installed or the conditions on-site, we do not guarantee the product's performance. We also accept no responsibility for any loss, damage, or injury resulting from the use of this information.