




System FC731

Penetration Detail: PVC Floor Waste (FWG) fire-stopped with Allproof Low Profile Fire Collar

Separating Element: Rib and Timber Infill floor, min. 70mm Concrete Topping on 25mm thick Timber Boards



ALLPROOF
INDUSTRIES

Installation Instructions:

1. Ensure substrate around pipe is flat and clear of obstructions.
2. Open pipe collar and position around pipe.
3. Slide tab through slot in pipe collar and fold back 180° to secure.
4. Secure pipe collar using M6x60 masonry anchors into the concrete slab, no plastic/nylon fixings.
5. Install only from underside of floor penetrations.

Services & Ratings (FRR)

Service Penetration	Pipe Size	Collar Size	Core Hole Size	FRR
PVC floor waste	80mm	ALLFC80	92mm	-/120/120
PVC floor waste	100mm	ALLFC100	117mm	-/120/120

Compliance

Compliance BRANZ Appraisal No. 1088(2025)
Standards AS1530.4-2014 & AS4072.1-2005

Firestop Centre Technical support:
Tel: +64 9 483 4000
info@firestopcentre.co.nz
www.firestopcentre.co.nz

Drawing Rev: 1.1

Scale: NTS

Disclaimer: Firestop Centre may change product specifications without notice as part of our ongoing development and testing. All information in this document is provided in good faith and for guidance only. All drawings are for illustration purposes only and may not reflect the actual product. Since we cannot control how the product is installed or the conditions on-site, we do not guarantee the product's performance. We also accept no responsibility for any loss, damage, or injury resulting from the use of this information.